



H2O Leather Color



Step	Photos	Description
1		<p>Before proceed with color restoration, wax and oil stain on surface must removed thoroughly, so that the color can stay permanently</p> <p>To use Otter Super Clean or Biocleaner to clean dirty stain on leather seats.</p>
2		<p>Use brush on stubborn stain.</p> <p>Clean with damp cloth and leave to dry.</p>
3		<p>To use fine brush to color on car seat, you may choose your desired color.</p> <p>2 to 3 coats may require for application of light color unless the based color is light.</p>
4		<p>The final look of car seat with various colors.</p> <p>You may apply a layer of Otter Hide Food for extra protection on leather.</p>